


DOGPOWEREDSCOOTER "OUTRIGGER"
 WWW.DOGPOWEREDSCOOTER.COM (SEARCH "GOOGLE.COM" UNDER "DOGPOWEREDSCOOTER")
 MARK SCHUETTE
 434 S.E. CLEVELAND AVE.
 BEND, OREGON 97102
 541-383-3845

REMOVE STOCK FOOTPLATE AND REPLACE
 W/ ALUM. OUTRIGGER PLATE
 BOLT DOWN TO FRAME BRACES BELOW
 (NOT SO TIGHT AS TO BEND THE BRACES)
 (CHECK THAT ARC IN FRONT IS SEATED/NO BINDING)
 (MAKE SURE IT RUNS PARALLEL TO SCOOTER FRAME)


HOLES MAY NOT LINE UP PERFECTLY (EACH SCOOTER
 IS SLIGHTLY DIFFERENT) SO YOU MAY NEED TO ENLARGE
 AND OR DRILL NEW HOLES!
 THEN BOLT OUTRIGGER BAR DOWN TO PLATE IN THE
 3 PLACES- BEFORE FINAL TIGHTENING SIGHT DOWN BAR
 AND MAKE SURE IT RUNS PARALLEL TO SCOOTER.

BRIEFLY- PUTTING THE SCOOTER TOGETHER:
 GET ALL THE PARTS OUT OF THE BOX-
 LOOK FOR THE REAR FENDER STAY WHICH MAY BE L
 LOOK FOR FRONT BRAKE CABLE SHEATHING WHICH MA
 TAKE OFF STOCK FOOTPLATE AND KICKSTAND
 CLAMP BOTTOM OF SCOOTER FRAME ACROSS CORNER
 PUT ON FENDERS
 PUT ON WHEELS
 PUT ON HANDLEBARS
 DO INITIAL BRAKE PADS ORIENTATION
 INSTALL BRAKE CABLES-DON'T FORGET RUBBER BOOTS
 BEGIN AT HANDLEBARS BY INSERTING CABLE END DRU
 PINCH BRAKE CALIPERS TOGETHER LOOSELY THEN TIGH
 CABLE SET SCREW AT CALIPER
 FINAL CABLE TIGHTENING AT HANDLEBAR LEVERS



VERTICALLY ADJUST "OUTRIGGER" ONTO THE POS
 SO THAT THERE IS 3"-5" OF CLEARANCE
 ABOVE THE TOP OF THE DOGS SHOULDERS.
 ADJUST SHOCK ABSORBER CLAMPS SO THEY
 AND ARE LEVEL W/ THE D-RINGS ON HARNESS
 (WITH THE SCOOTER VERTICAL)
 SHORTEN CARBINER CHAIN SO THAT A LITTLE
 TENSION IS ON RUBBER BAND WHEN DOG IS
 HARNESSSED IN FINAL POSITION

GETTING YOUR DOG GOING: OVERCOMING THE
 -PUT THE HARNESS ON YOUR DOG
 -GET YOUR DOG USED TO BEING UNDER THE B
 -WALK YOUR DOG AND THE SCOOTER WHILE HO
 UNDER THE BAR (GET HELPER & AVOID SHAR
 -PICK UP THE PACE/JOG-FOCUS HIS ATTENTIO
 -FINALLY HOOK THE DOG INTO THE D-RINGS
 -HOLD THE DOG IN CASE HE STARTS TO THRA
 -THEN WALK- THEN JOG- THEN FINALLY PUT Y
 -WEIGHT ON THE SCOOTER AND KICK TO HELP
 ALL THIS SHOULD TAKE 20 MIN. OR SO ON AV
 DON'T WORRY ABOUT SPEED/PULLING YET- IT



BEFORE GOING OUT SCOOTERING- CHECK EACH CLAMP FOR TIGHTNESS
 ALWAYS CARRY A TIRE PUMP (KEEP THE TIRES HARD) & FLAT REPAIR KIT.
 HARNESSSES ARE SIZED SMALL SO THAT THE PADDED CHEST STRAP RIDES AS HIGH AS POSSIBLE ABOVE THE
 SHOULDER SO THAT IT DOESN'T RESTRICT LEG EXTENSION-SHORTEN THE 4 VERTICAL HARNESS STRAPS IF IT DOES.
 STURDY FOOTWEAR AND BICYCLE HELMETS ARE RECOMMENDED.
 THE DOG CAN SIT AND EVEN LIE DOWN WHILE STILL HARNESSSED IN
 NEVER LEAVE YOUR DOG UNATTENDED WHILE HARNESSSED INTO THE SCOOTER

MOUNT BOTTSQ
 FOOTBOTTSQ
 MORE
 LESS